

Application instructions.

- Clean and survey the pipe to be repaired.
- Position board for life in safe working position, out of direct sunlight.
- Wrap packer with protective film at a 30° angle from the roll.

 *Ensure you have the correct packer for the size of pipe.
- Open Multi-Kit and textile pack.
- Put gloves on to protect your hands.
- Remove resin pack A & B.
- Remove resin lids, pour A into B and replace lid and agitate for approximately 45 seconds. Then repeat the process pouring the contents back into bottle A.
- Position liner textile one the board for life and pour resin through the middle of the textile.
- Impregnate the resin into the liner ensuring a thorough wetting out of the textile.
- When all the textile is impregnated slide the packer through the textile and secure with the elastic bands provided.
- Position the packer in the pipe at the point of repair and inflate to the correct pressure.
- Attach the pressure check gauge to the inflation hose or push rod and monitor the packer pressure whilst the patch is curing.
- Once the resin has cured, deflate the packer and remove it from the pipe.